


CARE & MAINTENANCE:

Glass Boards



Suggested Daily Care & Cleaning:

- Wipe surface with a clean cloth moistened with a liquid glass cleaner.
- Rinse with clear water.
- Wipe dry with clean, dry cloth.

Removing Soil Marks:

Soil marks (such as paint, oil, crayon stains, tape marks, etc.) that cannot be removed with washing may be removed without damage to the board surface by using household cleaners or cleaning fluids such as denatured alcohol or glass cleaner. Under no circumstances should cleaners that contain paint remover or abrasives be used.

Projection & Colored Glass Surfaces:

If your glass whiteboard has a matte projection surface, we suggest using a spray-on type of glass cleaner when erasing your marks. Simply spray the surface and briskly rub with a clean microfiber cloth. Rinse with clear water. Avoid using

caustic or abrasive type cleaners. If you ordered a black or colored glass whiteboard, you may need to use neon color markers in order for your writing to be clearly visible on the board surface. Depending on the color you order, we may include a set of neon markers for your convenience.

Alternative Glass Surface Cleaners:

- Mild soap and water
- Rubbing alcohol
- Glass surface cleaners
- Ceramic stove top cleaners

